





NQuire 300 series customer information terminal user guide

Disclaimer

© 2017-2018 Fujian Newland Auto-ID Tech. Co., Ltd. All rights reserved.

Please read through the manual carefully before using the product and operate it according to the manual. It is advised that you should keep this manual for future reference.

Do not disassemble the device or remove the seal label from the device, doing so will void the product warranty provided by Fujian Newland Auto-ID Tech. Co., Ltd.

All pictures in this manual are for reference only and actual product may differ. Regarding to the product modification and update, Fujian Newland Auto-ID Tech. Co., Ltd. reserves the right to make changes to any software or hardware to improve reliability, function, or design at any time without notice. The information contained herein is subject to change without prior notice.

The products depicted in this manual may include software copyrighted by Fujian Newland Auto-ID Tech. Co., Ltd or third party. The user, corporation or individual, shall not duplicate, in whole or in part, distribute, modify, decompile, disassemble, decode, reverse engineer, rent, transfer or sublicense such software without prior written consent from the copyright holders.

This manual is copyrighted. No part of this publication may be reproduced, distributed or used in any form without written permission from Newland.

Fujian Newland Auto-ID Tech. Co., Ltd. reserves the right to make final interpretation of the statement above.

Fujian Newland Auto-ID Tech. Co., Ltd. 3F, Building A, No.1, Rujiang West Rd., Mawei, Fuzhou, Fujian, China 350015 Http://www.newlandaidc.com

Revision History

Version	Description	Date
V1.0.0	Initial release.	March 31, 2017
	1. Added the "Enabling MTP" section in Chapter 2.	
	2. Added the Code ID editing and RFID programming features in	
V1.0.1	Chapter 3	
	3. Added a new chapter – Chapter 8 Using an External Barcode	July 6, 2017
	Scanner.	
	4. Added the "Code ID Table" in Appendix.	
	Note: Firmware version V1.00.006 or later is required for the new	
	features in Items 2 & 3 above.	
V1.0.2	Added the "GPIO Device" section in Chapter 4.	January 23, 2018

Table of Contents

Revision History	
Chapter 1 About This Guide	1
Introduction	
Chapter Descriptions	1
Chapter 2 Getting Started	2
Introduction to the NQuire	2
Unpacking	2
Product Outline	
LEDs on the NQuire	
Work Procedure	5
Mounting	5
Wiring	6
Physical Ports on the NQuire	6
Wiring Instructions	6
Installing the Micro SD Card	
Enabling MTP	8
Chapter 3 Configuring the NQuire	11
Introduction	11
Configuring the NQuire with the Web-based Tool	
Network Settings	
Messages Settings	
Scanner Settings	
Miscellaneous Settings	
Log Settings	21
Backup	
Time	
Update	24
Reboot	
Configuring the NQuire with Programming Barcodes	
Enter/Exit the Setup Mode	
Enable/Disable DHCP	
Screen Brightness	
Scanner Sensitivity	

Beeper	
Reboot	
Return to Desktop	
Query Configuration	
Customizing Configuration Barcodes	
Chapter 4 Using the NQuire	
Introduction	
Scanning Barcodes with NQuire301	
Scanning Barcodes with NQuire302/304	
Reading RFID Tags	
GPIO Device	
Chapter 5 ESC Commands	
Introduction	
Text Display	
NQuire Command Set	
Examples	
Chapter 6 System Update	
Introduction	
Updating System with a USB Flash Drive	
Updating System via FTP	
Chapter 7 ADB Debug	45
Introduction	45
Using the ADB	45
Chapter 8 Using an External Barcode Scanner	
Introduction	
Connecting a Barcode Scanner to the NQuire	
Configuring an External Barcode Scanner	
Configuring NLS-HR100	
Configuring NLS-HR22	51
Configuring NLS-HR11 Plus	
Configuring NLS-HR42	53
Configuring NLS-HR3290 (Corded)	54
Configuring NLS-HR15 (Corded)	55

Chapter 9 Maintenance& Troubleshooting	56
Maintenance	
Keeping the NQuire Dust-free	
Cleaning	
Troubleshooting	57
Appendix	
Sample Barcodes	
Code ID Table	59

Chapter 1 About This Guide

Introduction

This guide provides instructions for installing, programming and operating the NLS-NQuire300 series customer information terminal (hereinafter referred to as "the NQuire").

Chapter Descriptions

∻	Chapter 1 About This Guide	Provides general description of this manual.
¢	Chapter 2 Getting Started	Provides information on getting the NQuire up and running for the first time.
¢	Chapter 3 Configuring the NQuire	Describe how to program the NQuire with a web-based tool and with barcodes.
¢	Chapter 4 Using the NQuire	Explains how to scan barcodes, read RFID tags and use a GPIO device.
¢	Chapter 5 ESC Commands	Explains how to control the NQuire with ESC commands.
¢	Chapter 6 System Update	Introduces two methods to update system.
¢	Chapter 7 ADB Debug	Describes how to use the ADB tool.
¢	Chapter 8 Using an External Barcode Scanner	Describes how to configure an external handheld barcode scanner to work with the NQuire.
¢	Chapter 9 Maintenance & Troubleshooting	Provides troubleshooting solutions for issues that might occur when using the NQuire.
∻	Appendix	Provides some sample barcodes for the user to test the NQuire.

Chapter 2 Getting Started

Introduction to the NQuire

The NQuire (including NQuire301/302/304) is designed to read/scan, inform and interact with your customer.

This small and attractive information terminal reads multiple data carriers; from 1D barcodes (such as EAN/UPC) to complex 2D barcodes displayed on mobile phones. It also comes with unprecedented RFID reading capabilities.

The NQuire complies with the specifications of standard VESA 75 bracket, enabling easy mounting on shelves and walls. Furthermore, it is possible to add USB or Bluetooth (optional) peripherals to expand this solution with a printer, a handheld scanner for scanning large or bulky items, a magnetic stripe card reader and more.

The NQuire supports 10/100Mbps Ethernet, Wifi 802.11b/g/n (optional) and Bluetooth 4.0 LE(optional) and Power-over-Ethernet, so it can be easily integrated into your existing wireless or wired LAN.

The NQuire can be used for various applications such as Price Check, Inventory Check, Informational Product Videos, Gift Card/Coupon Lookup, Guided Selling, Digital Advertising/Signage, Call for Assistance, Store Maps and more.

Unpacking

Carefully remove all protective material from the pack and verify that the following items are present:

♦ NQuire300 x1



 \diamond Power adapter x 1, plug x 5



♦ VESA 75 mount x1, screwdriver x 1, port cover x 2



♦ Plastic wall anchor x 4, GPIO connector x 4, small screw x 6, large screw x 4



♦ Quick Start Guide x 1

Product Outline



1	Network LED	2	Good Read LED
3	LCD (Touch) Display	4	Speaker
5	"Where to Scan Barcode" Arrow	6	RFID Antenna
7	USB Host/Slave Port	8	USB Host Port
9	Power Jack	10	Ethernet Port
11	GPIO Connectors	12	Cable Trough

LEDs on the NQuire

Network LED						
Blue LED on Wifi/ Ethernet/ Bluetooth is available						
Good Read LED						
Green LED flashes once	A barcode has been scanned and decoded.					

Work Procedure

- 1. The NQuire receives its input via:
- ♦ 1D barcode scan engine (NQuire301) or
- ♦ 2D barcode scan engine (NQuire302/ NQuire304) or
- ♦ RFID reader.
- 2. The NQuire sends the input to application program which runs on a remote PC or server.
- 3. Application program sends information back to the terminal for display.

Mounting

The NQuire comes standard with a VESA 75 mount. The VESA 75 mount consists of a bracket and a chassis. Please follow the instructions below to mount the NQuire onto the VESA 75 mount.

Step 1: Select a mounting location that is convenient for operation.

Step 2: For wall mounting, install the four plastic expansion anchors in a wall and then secure the bracket of VESA 75 mount to the wall using the four large screws. For countertop/shelf mounting, secure the bracket of VESA 75 mount to a countertop/shelf using the four large screws.

Step 3: Attach the chassis of VESA 75 mount to the back of the NQuire using the four small screws.

Step 4: Follow the instructions in the following "Wiring" section to complete the cable connections. Then slide the NQuire into the bracket.



Wiring

Physical Ports on the NQuire

♦ Power jack:

It uses the center pin for positive and the outer tab for ground.

Input power requirement: DC 9-25V, 2A

♦ Ethernet port:

PIN	Description
1	Tx_D1+
2	Tx_D1-
3	Rx_D2+
4	BI_D3+/ PoE
5	BI_D3- / PoE
6	Rx_D2-
7	BI_D4+ / PoE
8	BI_D4-/ PoE



USB Host port: It can be connected to a handheld barcode scanner, printer, magnetic stripe card reader or other external device.

♦ GPIO connectors (General Purpose Input/Output interface):

Two in (Each contains 2 pins); two out (Each contains 2 pins)

Wiring Instructions

Select one of the following power supply solutions and make the cable connections accordingly.

Power adapter solution

Step 1: Put the NQuire face down. Remove the port cover on the right.

- Step 2: Attach the appropriate plug type to the power adapter and plug it into the power jack on the NQuire.
- Step 3: Lead the cable through the cable trough for appropriate routing.
- Step 4: Wired Ethernet: Connect an Ethernet cable to the Ethernet port on the NQuire, replace the port cover and fasten it with the screw.

Wireless Ethernet: Replace the port cover and fasten it with the screw.



Power-over-Ethernet (PoE) solution

- Step 1: Put the NQuire face down. Remove the port cover on the right.
- Step 2: Connect one end of an Ethernet cable to the Ethernet port on the NQuire.
- Step 3: Lead the cable through the cable trough for appropriate routing.
- Step 4: Replace the port cover and fasten it with the screw.
- Step 5: Connect the other end of the Ethernet cable to a PoE power module or a PoE switch (NOT supplied by Newland). The NQuire supports both the Mid-span and End-span PoE protocol.
- Step 6: Connect DC power to either the third-party PoE power module or PoE switch if required.



Note: Do not connect power adapter to the power jack on the NQuire when adopting PoE solution. Otherwise there is a risk of damage to the NQuire.

Installing the Micro SD Card

Step 1: Loosen the screw on the back cover of the NQuire and remove the back cover. Slide the slot cover rightward and lift the left end of it.



Step 2: Insert the Micro SD card into the slot, with its metal contacts facing down.

Step 3: Close the slot cover and slide it leftward until it clicks.

Step 4: Replace the back cover and fasten it with the screw removed in Step 1.

Enabling MTP

MTP (Media Transfer Protocol) lets you transfer files between your NQuire and a PC. To enable it, follow the steps below:

Step 1: Connect the USB Host/Slave port on the NQuire to PC with a USB cable (purchase separately).



Step 2: Follow the steps described in the "Using the ADB" section in Chapter 7 to enable OTG. Tap to return to the Settings menu.



Step 3: Tap "Storage".



Step 4: Tap and then "USB computer connection".



Step 5: Select "Media device (MTP)".

		ġ,	(0-	04:50	
<	USB computer connection				-
	CONNECT AS				
	Media device (MTP) Lets you transfer media files on Windows, or using Android File Transfer on Mac (see www.endroid.com/filetransfer)				
	Camera (PTP) Lets you transfer photos using camera software, and transfer any files on computers that don't support MTP				Û

Chapter 3 Configuring the NQuire

Introduction

You may configure the NQuire with the web-based tool or by scanning programming barcodes.

Configuring the NQuire with the Web-based Tool

The NQuire has a built-in web server which can be used for device configuration. This configuration method effectively bypasses the restrictions imposed by operating system. You may access the configuration tool by following the instructions below.

1. Open a web browser on your PC (IE11 is recommended).

2. Enter the NQuire's default IP address 192.168.1.200 in the address bar and then press Enter to open the NQuire configuration tool homepage.

Newland Configuration tool				
Home Network Messages Scanner	Welcome Device name Newland NQuire 300 Serial number n/a Hardware version V1.0 Firmware version NQuire 300_V1.00.002.EN			
Miscellaneous Log Backup Time	Application build date Mon Mar 20 20:13:08 CS1 2017 MAC ethernet 36:49:65:3d:84:1c MAC wifi 00:03:7f:04:02:12 Scanner module type EM1399 Scanner module firmware JNI: V1.01.026 2013032014			
Update Reboot	Current IP address 192.168.28.242			

If an error page is displayed, please try pinging the NQuire.

- i. Make sure your PC is in the same IP range as the NQuire, e.g. 192.168.1.198.
- ii. Type "ping 192.168.1.200" in your Command Prompt (MS Windows: cmd.exe) and then press Enter.
- iii. If the problem still persists, please double-check the IP address and physical Ethernet connection.

3. Click a menu item on the left pane and set the parameters as per your needs. When you finish making changes to the parameters in a box, click "Apply settings" to save the changes. For the details, see the following sections.

Network Settings

When you click "Network" in the menu, the following page opens. You can specify your own specific network settings here.

» Newland	J Configuration tool
A Home Network Messages Scanner Miscellaneous Log Backup	wifi ESSID Wireless key type WPA or WPA2 v Wireless key Use DHCP No @ Yes Apply settings
Time Update Reboot	Ethernet Use DHCP No Yes IP address 192.168.1.200 Netmask 255.255.255.0 Gateway 192.168.1.1 Nameserver 1 8.8.8.8 Nameserver 2 8.8.4.4 Apply settings
	NQuire protocol settings Mode UDP UDP port 9000 TCP port 9101 Remote IP address 192.168.1.190 Apply settings

Wifi: Set the SSID, wireless key, wireless key type and DHCP of the AP the NQuire is going to connect to.

1. Wireless key type: You can choose between three security levels:

None: No encryption key is needed. The NQuire is, via your wireless router, available to all Wifi enabled devices.

WEP: Entry-level encryption with a wireless key to limit network access.

WPA/WPA2: High-end encryption with a wireless key to limit network access.

2. Wireless key: Enter the key which is going to be used to encrypt wireless data communication.

Ethernet: Set the Ethernet port parameters.

Use DHCP: If DHCP is used, an IP address will be automatically assigned to the NQuire; if DHCP is not used, the NQuire has a fixed IP address.

NQuire protocol settings: Set the connect mode, UDP/TCP port and IP address of the server the NQuire is going to connect to.

- Set connection mode: server (UDP active), client (UDP active), (pure) UDP, TCP server (no UDP), TCP client (no UDP) and TCP client on scan (for non-continuous Ethernet connections such as ISDN). When in server mode, the NQuire will listen to connections on the configured TCP port; when in client mode, the NQuire will try to make the connection using the configured "remote IP address" and "TCP port". When there are multiple connections (server mode only), scanned data will be sent to all connected servers and sent to the configured UDP server port.
- 2. Set UDP/TCP port
- 3. Set remote IP address

Note: 1. The NQuire ignores Wifi when Ethernet is available.

2. When you finish making changes to the parameters in a box, do not forget to click "Apply settings" to save the changes.

Messages Settings

 \wedge

When you click "Messages" in the menu, the following page opens. You can configure idle/error messages and font size here.

Home	Idle message					
Network	Text	X Pos	Y Pos	Vert Align	Hor Align	Size
Messages	Welcome	0	10	top 🗸	center 🗸	large 🗸
Scanner	Scan your product	0	50 80	top 🗸	center V	small V
Miscellaneous	++++		Annterentia			Jindin 1
Log			Apply settin	igs		
Time						
Undete	Entor message					
Dpuate	Text	X Pos	Y Pos	Vert Align	Hor Align	Size
Reboot	Please ask for assistance	0	30	top 🗸	center V	small V
	ior assistance	U				Jinan 🕈
			Apply settin	igs		
	Font sizes					
	Font size small	18 🗸				
	Font size large	28 🗸				

Idle message: You can specify what message (containing three lines of text) to be displayed when nothing is scanned. You can define how long the NQuire wait before displaying the idle message after a scan by setting the idle message timeout, as instructed in the "Miscellaneous Settings" section.

- 1. X Pos/ Y Pos: Set the x and y positions (x: 0-239; y: 0-127) of pixel.
- 2. Vert Align/ Hor Align: Set the vertical/ horizontal alignment of text. X positions will be ignored unless horizontal alignment is set to "left"; y positions will be ignored unless vertical alignment is set to "top".
- 3. Size: Choose between small font and large font.

Error message: You can specify what message (containing two lines of text) to be displayed if the NQuire does not receive a response from the remote server within a preset period of time (i.e. error message timeout) after a scan. See the "Miscellaneous Settings" section to learn how to set the error message timeout.

- \Rightarrow X Pos/ Y Pos: Set the x and y positions (x: 0-239; y: 0-127) of pixel.
- ♦ Vert Align/ Hor Align: Align the text to a position. X positions will be ignored unless horizontal alignment is set to "left"; y positions will be ignored unless vertical alignment is set to "top".
- ♦ Size: Choose between small font and large font.

Font Size: Set the size of small/ large font by selecting an option from the corresponding dropdown list.

Note: When you finish making changes to the parameters in a box, do not forget to click "Apply settings" to save the changes.

Scanner Settings

When you click "Scanner" in the menu, the following page opens. You can configure barcode scanner and Mifare scanner parameters here.

	Dancoues		
ome	Output mode Output vi	API	
etwork	Scan Mode Normal n	ode	
essages	Encoding GBK	Vee	
canner	Enable barcode ID	Vos	
iscellaneous		165	
20			
	Symbologies Enable		
аскир	EAN419	◎ No NoYes	
ne	ISBN	No Ves	
date	CODE32	No Ves	
boot	EAN414	© No ⊛ Yes	
	G\$1128(UCC/EAN-128)	No Yes	
	EAN413	No Yes	
	EAN-13	No Ves	
	QR	© No .● Yes	
	ITF-6	© No ⊚ Yes	
	EAN-8	No ves	
	GS1-Databar (RSS)	© No ● Yes	
	UPC-A	○ No ● Yes	
	Code 93	© NO ♥ Yes	
	AIM 128	○ NO ◎ Yes	
	LIPCE	■ NO ■ Yes	
	ITE-14		
	Industrial 25	No Ves	
	Codabar	No Ves	
	Matrix 2 of 5	No Ves	
	ISSN	© No ● Yes	
	MSI-Plessev	No Ves	
	Code 11	No Ves	

Barcodes

- 1. Output mode
- ♦ Output via API: Application acquires scanned data by receiving system broadcasts. For the preinstalled CIT app, you should select this output mode.
- ♦ Simulate keystroke: Output scanned data to keyboard buffer to simulate keyboard input.
- ♦ Fill in EditText directly: Output scanned data at the current cursor position in EditText.
- 2. Scan Mode
- ♦ Normal mode: Presenting a barcode to the NQuire activates a decode session.
- ♦ Continuous mode: The NQuire automatically starts one decode session after another.
- 3. Encoding: Choose a character encoding to interpret barcode data.
- ♦ UTF-8: Dominant Unicode encoding.
- ♦ GBK: A character encoding for Chinese characters.
- ♦ ISO-8859-1: A common character encoding which covers Western European languages.

- 4. Add a line feed: Choose whether to add a line feed after each barcode scanned.
- 5. Enable barcode ID: Choose whether to add Code ID before each barcode scanned; customize the Code IDs for symbologies. To add Code ID before scanned data, select "Yes" beside the "Enable barcode ID" item and then click "Apply settings". To set the Code ID of a symbology, select "Yes" beside the "Enable barcode ID" item, enter your desired Code ID in the corresponding text box beside that symbology and then click "Apply settings". To restore the default Code IDs of all symbologies, select "Yes" beside the "Enable barcode ID" item and then click "Default ID". See the "Code ID Table" in Appendix for a complete list of default Code IDs.

Newland Config	juration tool	_			
	Barcodes				*
Home	Output mode Output via Al	PI 🔹			
Network	Scan Mode Normal mode				
Network	Encoding GBK	•			
Messages	Add a line feed No Ye	es			
Scanner	Enable barcode ID ON ON	es			
Miscellaneous					
Log	Symbologies Enable		CodelD		
Backup			CodelD		=
Time	EAN419	© No ♥ Yes	EAN419	x	
Update	CODE32	No Ves	ISBN	e	
Reboot	EAN414	No Ves	CODE32	t	
Rebool	GS1128(UCC/EAN-128)	No Ves	CS1129/UCC/EAN 129)	W D	
	EAN413	No Yes	FAN413	r v	
	EAN-13	No Yes	Code 128	#	
	QR	No Yes	EAN-13	F	
	ITF-6	No Yes	QR	S	
	EAN-8	○ No ● Yes	EAN-8	FF	
	UPC-A	No Ves	GS1-Databar (RSS)	R	
	Code 93	No e Yes	UPC-A	d	
	AIM 128	No Yes	Code 93	c	
	Plessey	No Yes	AIM 128	a	
	UPC-E	No Yes	LIPC-E	q b	
	ITF-14	No Yes	Industrial 25	m	
	Industrial 25	○ No	Codabar	%	
	Codabar Matrix 2 of 5	© No ◎ Yes	Matrix 2 of 5	1	
	ISSN	No Ves	ISSN	9	
	MSI-Plessev	No Ves	MSI-Plessey	0	
	Code 11	No Ves	Code 11	n	-
51 2 2					
Newland Config	guration tool				
1	Code 93	© No. ● Yes	1		
	AIM 128	No Yes	Code 93	c	
Home	Plessey	No Yes	AIM 128	a	
Network	UPC-E	No Yes		q	
Menograp	ITF-14	No Yes	Industrial 25	D	
messages	Industrial 25	No Yes	Codabar	%	
Scanner	Codabar	No Yes	Matrix 2 of 5		
Miscellaneous	Matrix 2 of 5	No Ves	ISSN	g	
Log	MSI Plassay	NO Ves	MSI-Plessey	0	
Backup	Code 11	No Ves	Code 11	n	
Time	PDF417	© No ● Yes	PDF417	r	
Update	DATAMATRIX	No Yes	DATAMATRIX	u	
Pohoot	Code 39	No Yes	Code 39	*	
Kebool	Standard 25	No Yes	Standard 25	k	
	Interleaved 2 of 5	No Yes	Interleaved 2 of 5	<u> </u>	
		Apply setting	IS Default ID		
	1				1

6. Symbologies Enable: Choose whether to enable the NQuire to identify the symbologies.

Note: When you finish making changes to the parameters in a box, do not forget to click "Apply settings" to save the changes.

Mifare scanner: Besides scanning barcodes, the CIT app that comes preinstalled on the NQuire also allows users to read from and write to Mifare Classic Mini/1K/2K/4K tags/cards. The following provides instructions for setting the Mifare scanner parameters.

Rfid message prefix	MF
Access key A	FFFFFFFFFF
Sectors to read	
Cardnum formatting	hexadecimal 💌
Send card number only	No Ves
Sector data format	base 64 💌
Sector data seperator	none 💌
Suppress scan beep	No Yes
Access violation	Card access\ndenied
Incomplete scan	Wait for beep\nwhen scanning
Write error message	Transaction failed!\n\nThis is logged.
	Apply settings

- 1. Rfid message prefix: Enter the character(s) (up to 5 characters) you want to add before RFID message.
- 2. Access key A: Enter the access key A as hexadecimal characters (no key B can be inserted) which has been defined for your Mifare tags/cards.
- 3. Sector to read: Define which sector(s) and block(s) of the Mifare tag/card should be read in the format of **sector:block,sector:block,...sector:block**. For example, **14:0,14:1,15:0** means to read blocks 0 and 1 in sector 14 and block 0 in sector 15.
- 4. Cardnum formatting: Specify whether tag/card number is transmitted as a hexadecimal number or a binary number.
- 5. Send card number only: No sectors will be read, just the tag/card number will be sent to the server.
- 6. Sector data format: Specify whether sector data is transmitted in binary, base64 or hexadecimal format.
- 7. Sector data separator: Specify what separator is used to separate the different blocks read.
- 8. Suppress scan beep: Set whether to turn off the beep when the NQuire reads a tag/card.
- 9. Access violation/ Incomplete scan/ Write error message: You can change these messages as per your actual needs.

Note: When you finish making changes to the parameters in a box, do not forget to click "Apply settings" to save the changes.

Miscellaneous Settings

When you click "Miscellaneous" in the menu, the following page opens. You can configure scanner parameters here.

Newland	Configuration tool
^	Device
Home	
Network	Device name Newland NQuire 300
Messages	Apply settings
Scanner	
Miscellaneous	
Log	Authentication
Backup	Enable authentication
Time	Username
Update	Password
Reboot	
	Apply settings
	Programming barcode security
	Programming mode timeout
	Barcode programming security code 0000
	Apply settings
	, white a second s
	Text and messages
	Idle message timeout 3
	Error message timeout 1
	Scan event separator
	Message encryption none
	Use Custom NQuire identifier
	Custom NQuire identifier \${serial}:
	Apply settings
	Disable beep after scan ONO OYes
	Enable persistent immersive ON0 © Yes
	Display brightness 30 V
	Scanner sensitivity high 🗸
	Apply settings
	GPIO
	Append event counter
	Method On read GPIQ V
	Poll speed (seconds)
	Apply settings
	Control of the second sec
	Tanakaanaa
	Touch message prefix K
	I OUCH Keyboard timeout[seconds] 60
	Apply settings

Device name: Type a random name used for your own administration.

Authentication: You can set a username and password to allow only authorized personnel to log in to the NQuire configuration tool.

Programming barcode security

- 1. Programming mode timeout: The period of time allowed to elapse before the NQuire returns to idle state when no programming barcode is scanned in seconds. When the timeout expires, the NQuire automatically exits the setup mode.
- Barcode programming security code: You can set a security code to allow only authorized personnel to program the NQuire with barcodes. After a security code is set and enabled, you need to follow the procedure below for barcode programming: Scan the Enter Setup barcode, then the security code then the other programming barcodes.

Text and messages

- 1. Idle message timeout: The period of time before the idle message is displayed after a scan in seconds.
- 2. Error message timeout: The period of time the NQuire waits for a response from the remote server in seconds. When the timeout expires, the error message will be displayed for 5 seconds.

Codepage	Description
851	DOS Greek
852	"Multilingual" West European Latin-1
866	Cyrillic DOS codepage
874	Thai
1250	Central and East European Latin
1251	Cyrillic
1252	West European Latin-2
1253	Greek
1254	Turkish
1257	Baltic

3. Font codepage: Choose either UTF-8 (a multi-byte codepage, universal fontset which supports most used language fonts) or one of the following single-byte codepages.

- 4. Scan event separator: Scan event separator is added after each barcode scanned. You can set the separator to LF, CR or CRLF.
- 5. Message encryption: Choose "none" or "base64" as per your application needs.
- 6. Use custom NQuire identifier: NQuire identifier can be used to distinguish data acquired by one NQuire unit from another. You can choose whether to send the user-defined NQuire identifier or not after a scan. The default NQuire identifier is \${serial} which means the NQuire's serial number.
- 7. Currency symbol: When a single-byte codepage is selected, received ASCII value 0x80 is displayed as the currency symbol chosen here.

Interaction

- 1. Disable beep after scan: Enable or disable the emission of good read beep.
- 2. Enable launch CIT on boot: Choose whether to start built-in CIT app on boot or not.
- 3. Enable persistent immersive: If you disable the persistent immersive mode by selecting "No", the status bar and navigation bar will appear with an inward swipe from the top or right edge of the screen when the CIT app is in the immersive mode.
- 4. Display brightness: Choose an appropriate screen brightness level as per the user environment.
- 5. Scanner sensitivity: There are three options for setting the IR sensitivity. Choose an appropriate sensitivity level that fits the user environment.

GPIO

- 1. Server message prefix: Set the prefix that will be added before GPIO input data.
- 2. Append event counter: Choose to append the count of signal level changes or not as per your actual needs.
- 3. Method: Choose one of the following three methods to read data from GPIO port:

On read GPIO–Read data using a read command

On change - Read data when signal level changes

Poll-Read data by polling the port

4. Poll speed(seconds): Set the polling interval.

Touch screen

- 1. Server message prefix: You can define a prefix so that the database identifies the touch "key" similar to identifying a barcode.
- 2. Touch keyboard timeout(seconds): The time during which the keyboard/button is shown on the screen before the NQuire returns to idle state.

Note: When you finish making changes to the parameters in a box, do not forget to click "Apply settings" to save the changes.

Log Settings

When you click "Log" in the menu, the following page opens. You can configure and manage log level settings here.

lome	System log
letwork	
	beginning of /dev/log/system
lessages	03-21 06:00:02.417 D/NquireLog(697): nquiremainservice> MainService.onCreate
canner	03-21 06:00:02.592 D/NquireLog(697): nquiremainservice> SetupSocketThread.run
lissellanoous	03-21 00:00:02.634 D/NquireLog(097): nquiremainservice> MainService onStartCommand 03-21 06:00:02.634 D/NquireLog(697): nquiremainservice> nquiresyssettingsservice connected
inscenarieous	03-21 06:00:02.883 D/NquireLog(697): nquiremainservice> nquire350main connected
.og	03-21 06:00:02.894 D/NquireLog(697): nquiremainservice> nquireupdateservice connected
	03-21 06:00:02.916 D/NquireLog(993): nquire300main> DisplayActivity onCreate 03-21 06:00:02 944 D/NguireLog(1008): nguireundateservice> no undate nackage in exted
васкир	03-21 06:00:02.944 D/NquireLog(1008): nquireupdateservice> no update package in extsd.
Time	03-21 06:00:02.944 D/NquireLog(1008): nquireupdateservice> Can not get update package in udisk
	03-21 06:00:02.986 D/NquireLog(993): nquire350main> DisplayActivity onStart
Jpdate	03-21 06:00:02.989 D/NquiteLog(993): nquiteSomain> nquiteSocomm1 mead mead start 03-21 06:00:03 026 D/NquiteLog(993): nquiteSomain> nquitessettingsservice connected
aboot	03-21 06:00:03.112 D/NquireLog(993): nquire350main>
Repool	citServiceConnection.onServiceConnected
	03-21 06:00:03.164 D/NquireLog(993): nquire350main> restart remote connection. nquire protocol
	mode.oDr 03-21.06:00:03.170.D/NouireLog(.993): nouire350main> UdpClientThread thread start
	03-21 06:00:03.214 D/NguireLog(993): nguire350main> UdpClientThread connect to remote udp
	server. remote ip:/192.168.1.190 remote udp port:9000 local ip:/192.168.28.242 local udp port:9000
	03-21 06:00:06.152 D/NquireLog(993): nquire350main> restart remote connection. nquire protocol
	mode:UDP
	03-21 00:00:06 162 D/NquireLog(993): nquire300main> UdpClient1nread thread start
	server, remote in:/192.168.1.190 remote udp port:9000 local in:/192.168.28.242 local udp.port:9000
	Log settings
	Logging level info V

Note: When you finish making changes to the parameters, do not forget to click "Apply settings" to save the changes.

Backup

When you click "Backup" in the menu, the following page opens. You can import/export configuration data here.

Newland Configuration tool			
Home Network	Backup Click the button below to backup settings: Backup		
Messages Scanner			
Miscellaneous Log	Restore Click the button below to Restore settings: Browse Restore		
Backup			
Time Update			
Reboot			

Backup: Export all settings from the configuration tool into a json file.

Restore: Import a configuration file into the NQuire.

Time

When you click "Time" in the menu, the following page opens. You can set date and time here.

Newland	Configuration tool
A Home (Network (Messages (Scanner (Miscellaneous (Log (Backup (Time Automatic date & time Image: No Ores Year 2017 v Month Image: No Ores Hour 14 v Minute 24 v Apply settings Apply settings
Time Update Reboot	Automatic time zone No OYes Timezone GMT (GMT+0:00) Apply settings

Time

Automatic date & time: Choose whether to automatically adjust the date and time of the NQuire or not. Make sure the NQuire is properly connected to the Internet before using this feature.

Timezone

Automatic time zone: Choose whether to automatically adjust the time zone of the NQuire or not. Make sure the NQuire is equipped with a cellular module and a SIM card from your local carrier before using this feature.

Note: When you finish making changes to the parameters in a box, do not forget to click "Apply settings" to save the changes.

Update

When you click "Update" in the menu, the following page opens. When you want to update system via FTP, you can set the FTP server here.

Newland Configuration tool			
A Home Network Messages Scanner Miscellaneous Log Backup Time Update Reboot	IP Port User Password Path	192.168.1.190 21 anonymous	

Note: When you finish making changes to the parameters, do not forget to click "Apply settings" to save the changes.

Reboot

When you click "Reboot" in the menu, the following page opens. You can reboot the NQuire and reset it to factory settings here.

» Newland	Configuration tool
^	
Home	Device
Network	Click the button below to reboot the device:
Messages	Reboot
Scanner	Click the button below to reset factory default settings and reboot the
Miscellaneous	device:
Log	Defaults
Backup	
Time	
Update	
Reboot	

Resetting the NQuire to factory settings will delete all data in user space, including user-defined settings and user-installed apps.

Configuring the NQuire with Programming Barcodes

The NQuire can be configured by scanning programming barcodes which are created in the format of Code 128.

Enter/Exit the Setup Mode

Scanning the **Enter Setup** barcode can enable the NQuire to enter the setup mode. Then you can scan a number of programming barcodes to configure the NQuire. To exit the setup mode, scan the **Exit Setup** barcode.





Exit Setup

Enable/Disable DHCP

If DHCP is disabled, the NQuire will have a fixed IP address and it will use the most recently configured IP address. The default IP address is 192.168.1.200

If DHCP is enabled, the NQuire will function in DHCP mode and it is not necessary to put your own network environment in the default range 192.168.1.xxx



Enable DHCP



Disable DHCP

Screen Brightness



Level 1 (Low)



Level 3 (High)

Scanner Sensitivity



Normal



Max



Level 2 (Medium)



Level 4 (Extra High)



High

Beeper



Beeper OFF



Beeper ON

Reboot



Reboot



Restore Factory Settings & Reboot

Return to Desktop



Return to Desktop

Query Configuration



Query Configuration

Customizing Configuration Barcodes

To streamline the programming process, you may as well create 2D Data Matrix barcodes using existing JSON configuration files or those (cit.json) exported from the web-based NQuire configuration tool. Refer to the "Backup" section in this chapter to learn how to export configuration files from the tool. Note that the data of a customized configuration barcode should be a valid JSON object. It is recommended that you export configuration file using the NQuire configuration tool and then edit it as per your needs.

The following is an example of a user-defined configuration barcode.



{"Network Ethernet": {
 "Gateway": "192.168.28.254",
 "Netmask": "255.255.255.0",
 "Nameserver1": "8.8.8.8",
 "Nameserver2": "8.8.4.4",
 "Use DHCP": "No",
 "IP address": "192.168.28.246"
}}

To put a user-defined configuration barcode into use, scan the following barcodes. (Use the example above.)



Enter Setup



Enable User-Defined Configuration Barcode





Batch Barcode



Chapter 4 Using the NQuire

Introduction

The NQuire receives its input via:

- ♦ 1D barcode scan engine (NQuire301) or
- ♦ 2D barcode scan engine (NQuire302/ NQuire 304) or
- ♦ RFID reader.

To scan a barcode or read an RFID tag with the NQuire, follow the instructions below. You may scan a barcode in the "Sample Barcodes" section in Appendix to check if the NQuire reads barcode properly.

Scanning Barcodes with NQuire301

NQuire301 is only able to read 1D barcodes. It emits a red strip-shaped aiming beam to help the user to easily position the target barcode within the terminal's field of view to increase scan efficiency.



Optimal Scan Angle



Optimal Scan Distance

Scanning Barcodes with NQuire302/304

NQuire302/304 is able to read 1D and 2D barcodes. It emits a red crosshair aiming pattern to help the user to easily position the target barcode within the terminal's field of view to increase scan efficiency.



Reading RFID Tags

NQuire 301/302/304 is equipped with an RFID reader, which is widely used for access control applications. To read an RFID tag or card, place it 0-5cm in front of the RFID antenna.



GPIO Device

The NQuire supports interfacing with a GPIO device such as an entry/exit gate, door lock or LED lamp by connecting the signal wires to the GPIO ports.

The pin definitions of the GPIO ports are as follows:

CN16 PN2 CN16 PN1 CN13 PN2 CN13 PN1	OUT1- OUT1+ OUT2- OUT2+	
CN12 PN2 CN12 PN1	IN1+ IN1-	
CN11 PN2	IN2+	البيدي
CN11 PN1	IN2-	

Command to set GPO output

\x1b\x7e<param1><param2>
Parameter definition:
Param1:\x30 = OUT1
\x31 = OUT2
Param2:\x30 = low
\x31 = high
E.g. setting OUT2 to low:
\x1b\x7e\x31\x30

Command to get GPI input

\x1b\x7f<param>
Param can be 1 of:
\x30 = IN1
\x31 = IN2
E.g. requesting the state of IN1:
\x1b\x7f\x30
This send the value back using the following format:
<prefix><pin><value>
E.g. with the default prefix for IN1, value high:I01



Please find below an example of how a GPO integration could look like:

Output:

	Out High	Output Low
OUT1/OUT2	High	Open
LED	ON	OFF
GPIO	High	Low

Input:

	Input High	Input Low
S1/S2	Close	Open
GPIO	High	0V
IN1/IN2	Low	High

Voltage	3.3V	5V	9V	>9V
R1/R2	0Ω	0Ω	0Ω	(50*VCC-390)Ω

Chapter 5 ESC Commands

Introduction

The NQuire supports ESC commands that perform device controls such as controlling cursor, clearing screen and aligning text.

Text Display

The NQuire uses proportional fonts (every single character has its own specific width) for displaying text. For example, the letter "i" takes up much less horizontal space than the letter "m". As a result, you hardly know precisely how many characters fit on one line. If a text is too long to fit on one line, some characters will not be shown on the screen. Averagely speaking, up to 20 characters can be display on a single line.

Note: Every received ASCII value (between 20 and 255), which is not part of a command, is normally displayed on the screen.

The following commands control the position and control of text:

- ♦ Carriage Return (for going to the start position of the next line): ESC 0x0D
- ♦ Line Feed (for going to the start position of the next line): ESC 0x0A
- ♦ Set cursor (for predefined cursor positions): ESC 0x27
- ♦ Set pixel position (for placing the cursor on any pixel location): ESC 0x2C
- Align text (for aligning text to a position such as center of the screen, right of the screen) : ESC 0x2E

Nyune Commany Sec	NQuire	Command	Set
-------------------	--------	---------	-----

ESC	HEX	DEC	CHAR	DESCRIPTION	PARAMI	ETER
ESC	24 or 25	36 or 37	\$ or %	Clear the screen and move the cursor to the top-left corner of the screen.		
ESC	27	39	6	Set the cursor position ¹	<pos> 0x30-0x3F</pos>	<line> 0x30-0x34</line>
ESC	2C	44	,	Set the current pixel position ²	<pos> 0x30-0xAF</pos>	<line> 0x30-0X6F</line>
ESC	2E	46		Align a string of text ³	<align>0x30-0x3E</align>	<data>""[0x03]</data>
ESC	42	66	В	Select a font set Small font: 0x30 Large font: 0x31	<fontset>0x30-0x31</fontset>	
ESC	5A	90	Z	Reboot the NQuire		
ESC	5B	91	[Enable/disable barcode scanning	<mode> Disable: 0x30 Enable: 0x31</mode>	
ESC	5E	94	^	Generate the default beep		

¹ The actual pixel position depends on the currently selected font set:

- \diamond Every x-position is a multiple of 8 pixels.
- ♦ Every y-position depends on the currently selected font set (height of 24 or 32 pixels)

² This allows a text to be displayed anywhere on the screen. Note that a character will be partly displayed when it does not fully fit on the screen.

³Display a text, using the currently selected font set, on a calculated position on the screen.

<align></align>	DESCRIPTION
0x30	Left top
0x31	Center top
0x32	Right top
0x33	Left center
0x34	Center
0x35	Right center
0x36	Left bottom
0x37	Center bottom
0x38	Right bottom

<align></align>	DESCRIPTION
0x39	Left, using current y-coordinate
0x3A	Center, using current y-coordinate
0x3B	Right, using current y-coordinate
0x3C	Top, using current x-coordinate
0x3D	Center, using current x-coordinate
0x3E	Bottom, using current x-coordinate

<DATA> field has a maximum length of 25 characters. Use 0x03 (ETX) as the last character, if less characters are used.

Examples

Example 1

COMMAND	DESCRIPTION
<esc> 0x42 0x30</esc>	Small font
<esc> 0x25</esc>	Clear the screen, move
	cursor to top left corner
"Cheese"	Text to be displayed
0x0d	Carriage Return
"500 gr."	Text to be displayed
<esc> 0x42 0x31</esc>	Large font
<esc> 0x2E 0x38 "€ 5.69" 0x03</esc>	Align text to right bottom

Cheese 500 gr. € 5.69

Example 2

COMMAND	DESCRIPTION
<esc> 0x42 0x31</esc>	Large font
<esc> 0x24</esc>	Clear the screen, move
<esc> 0x2E 0x31 "Special offer!"0x03</esc>	Align text to center top
<esc> 0x42 0x30</esc>	Small font
<esc> 0x2E 0x34 "6-pack water 0.5L" 0x03</esc>	Align text to center
<esc> 0x42 0x31</esc>	Large font
<esc> 0x2E 0x37 "€ 0.99" 0x03</esc>	Align text to center bottom

Special offer! 6-pack water 0.5L € 0.99

Chapter 6 System Update

Introduction

The NQuire system can be updated using a USB flash drive or via FTP.

Updating System with a USB Flash Drive

1. Download the NQuire OTA update zip file from the Newland website at <u>www.newlandaidc.com</u> and save it under the root directory of a USB flash drive (FAT32 format). Do not change the file name.



2. De-energize the NQuire, plug the USB flash drive into the USB Host or USB Host/Slave port on the back of the NQuire and re-energize the NQuire. Then the NQuire will automatically begin the update process.

3. Wait for the update process to complete and for the NQuire to automatically reboot.

Updating System via FTP

1. Ensure that the NQuire and the FTP server are on the same LAN, that network settings are properly configured for the NQuire and that you can connect to the FTP server. Open a web browser and access the NQuire Configuration Tool homepage. Click "Update" and then configure the FTP server and click "Apply settings" to save the settings. For more information, see the "Update" section in Chapter 3.

🔊 Ne	wland	Conf	iguration tool	
	^			
Home	L Г	FTP		
Network				
Messages		IP	192.168.1.190]
Scanner		Port	21]
Miscellaneous		User Password	anonymous]
Log		Path]
Backup			Apply settings	d
Time				
Update				
Reboot				

2. Create a directory called "nquire300" under the FTP server's root directory.

€	Computer 🕨	Local Disk (C:)	▶ ftp ▶	•	f	Search	1 ftp			
Organize 🔻	📜 Open	Include in libra	ary 🔻	Share with	•	New fol	der	:==	•	?
Name	<u>^</u>		Date mod	lified	Туре		Size			
퉬 nquire300			3/21/2017	7 7:09 PM	File fo	older				



3. Create three directories named "ota", "config" and "res" in the nquire300 directory.

4. Download the NQuire OTA update zip file from the Newland website at <u>www.newlandaidc.com</u> and save it in the ota directory. Do not change the file name.

Organize Include in library Name Date modified Type Size md5.sum 3/20/2017 4:38 AM SUM File Newland_NQuire300_V1.00.002.EN_ota_update.zip 3/20/2017 4:40 AM	
Organize ▼ Include in library ▼ Share with ▼ New folder Image: Size Name Date modified Type Size Image: mathematic modified Type Size Image: mathematic modified Type Size Image: mathematic modified 3/20/2017 4:38 AM SUM File Image: mathematic mathematic modified 3/20/2017 4:40 AM Compressed (zipp Image: mathematic mathemathematic mathema	
Name Date modified Type Size md5.sum 3/20/2017 4:38 AM SUM File Newland_NQuire300_V1.00.002.EN_ota_update.zip 3/20/2017 4:40 AM Compressed (zipp 184	1
☐ md5.sum 3/20/2017 4:38 AM SUM File ▲ Newland_NQuire300_V1.00.002.EN_ota_update.zip 3/20/2017 4:40 AM Compressed (zipp 184	
Newland_NQuire300_V1.00.002.EN_ota_update.zip 3/20/2017 4:40 AM Compressed (zipp 184	1 KB
	283 KB

5. Create a text file named md5.sum inside the ota directory. This text file will contain the md5 value of the NQuire OTA update zip file and the fliename of the zip file separated by a space character, as shown below.

🗌 md5.sum - Notepad 📃 💷 💌
Edit Format View Help
Edit Format View Help F3fedfb230571e4497ff89860e161e8a Newland_NQuire300_V1.00.002.EN_ota_update.zip
-

6. If you want to import a configuration file into the NQuire, place the configuration file in the config directory.



7. If you want to upload resource files such as pictures and video clips to the NQuire, place the files and a text file named md5.sum in the res directory. This text file will contain the md5 value and filename of each resource file separated by a space character. Note that any existing resource files on the NQuire that are not listed in the md5.sumtext file will be deleted after the NQuire downloads resource files from the FTP server and that resource files to be downloaded should not exceed available user storage space on the NQuire (2G bytes in total).

	ee 64m -				Canada			
	≪ ftp i n	quire300 ▶ r	es	▼ * j	Search res			
Organize 🔻	Include i	n library 🔻	Share with 🔻	Slide show	New folder		•	
Name		Date		Туре	Size	Tags		
android_log	go.png	3/19/2017 6	26 PM	PNG image	1 KB			
mas.sum		5/19/2017 0	942 PIVI	SOM FILE	1 ND			
] md5.sum - No	otepad							•
) md5.sum - No ile Edit Forr 2039a87114	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d logo, png				
) md5.sum - No ile Edit Forr oc39a87114	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_1ogo. png				•
] md5.sum - No ile Edit Forr bc39a87114	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_logo.png				
) md5.sum - No ile Edit Forr bc39a87114	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_logo.png				
] md5.sum - Na ile Edit Forr bc 39a87114 :	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
) md5.sum - Nd ile Edit Forr bc39a871143	otepad nat View 88c1b688	Help 11c2875c6	d594 androi	d_logo.png				
] md5.sum - No ile Edit Forr DC39a871143	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_logo.png				
) md5.sum - No ile Edit Forr bc39a871143	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
) md5.sum - No ile Edit Forr bc39a87114	otepad nat View 88c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
) md5.sum - Na ile Edit Forr oc 39a87114 :	otepad nat View 88c1b688	Help 11c2875c6	d594 androi	d_logo.png				
) md5.sum - Nd ile Edit Forr bc39a871143	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_logo.png				
) md5.sum - Nd ile Edit Forr bc39a871143	otepad nat View 8c1b688	Help 11c2875c6	d594 androi	d_logo.png				
] md5.sum - No ile Edit Forr bc39a87114	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
) md5.sum - No ile Edit Forr bc39a87114	otepad nat View 86C1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
] md5.sum - No ile Edit Forr bc39a87114	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
) md5.sum - No ile Edit Forr bc39a87114	otepad nat View 88c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
) md5.sum - Nd ile Edit Forr bc39a871143	otepad nat View 38c1b688	Help 11c2875c6	d594 androi	d_logo.png				
] md5.sum - Ni ile Edit Forr oc39a871143	otepad nat View 8c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				
j md5.sum - No ile Edit Forr oc39a87114	otepad nat View 88c1b688	Help 11c2875c6	d594 androi	d_1ogo.png				

8. Enable FTP service and reboot the NQuire. Then the NQuire will attempt to connect to the FTP server and perform the following steps:

i. If the NQuire detects that there is a later version available on the FTP server, it will automatically reboot and begin the update process.

ii. The NQuire will automatically download the resource files in the res directory that are currently unavailable on NQuire to /mnt/sdcard/nquire300/res. Your application program may access these files via the path or using Environment.getExternalStorageDirectory()+"/nquire300/res", and use them with remote commands, such as display picture command.

iii. The NQuire will automatically download the configuration file from the FTP server if there is one. Note that a reboot is not needed for the new configuration to become effective.

Chapter 7 ADB Debug

Introduction

ADB (Android Debug Bridge) tool can be used to debug apps developed for the NQuire. The following section describes how to use the ADB.

Using the ADB

1. Turn on the NQuire. If it displays other screen other than the desktop, scan the **Enter Setup** barcode then **Return to Desktop** barcode to return to the desktop.



Enter Setup



Return to Desktop

2. Tap "Settings" on the desktop.



3. Tap "About tablet".



4. Tap "Build number" 7 times to become a developer.

ļ		⊿ 🗎 07:15	
<	🔯 About tablet		_
	Kernel version		'U
	3.4.39+ quewl@Ubuntu14-lanfs #42 Thu Mar 23 14:08:42 CST 2017		
	Build number NQuire300_V1.00.002.EN		
	SN		¢
	n/a		

5. Tap \frown to return to the previous screen.

₫ 2	⊿ 🔳 07:31	
र 🄯 About tablet		_
Kernel version		
3.4.39+ quewl@Ubuntu14-lanfs #42 Thu Mar 23 14:08:42 CST 2017		
Build number NQuire300_V1.CO. • You are now a developer!		
SN n/a	(Ĵ

6. Tap "Developer options".



7. Select "Enable OTG".

r 🖉	⊿ 🛯 07:32	
< 🔯 Developer options	ON	Г
Enable OTG Switch one of USB ports to OTG port		
Take bug report		\Box
Desktop backup password Desktop full backups aren't currently protected		Û

8. Connect the USB Host/Slave port on the NQuire to PC with a USB cable (purchase separately).



9. Tap "OK".



Chapter 8 Using an External Barcode Scanner

Introduction

Usually users scan a barcode by presenting it the NQuire. However, that may pose a challenge to them when scanning heavy, oversized or bulky items. In this case, using an external handheld barcode scanner can be an ideal solution.

Connecting a Barcode Scanner to the NQuire

Users can connect one of the Newland barcode scanners listed in this Chapter to the USB Host/Slave port or the USB Host port on the NQuire with a USB cable (purchase separately). When using the USB Host/Slave port, OTG must be disabled by unselecting "Enable OTG" on the NQuire. For more information, see the "Using the ADB" section in Chapter 7.



Configuring an External Barcode Scanner

The following sections provide the programming barcodes users may need to configure an external barcode scanner to work with the NQuire.

Configuring NLS-HR100

Use the barcode scanner to scan the barcodes below row by row, starting with the top left **Enter Setup** barcode, going from left to right, and ending with the **Exit Setup** barcode.



Enter Setup



Restore All Factory Defaults



Enter Setup



USB COM Port Emulation



Enable AIM ID Prefix



Disable Terminating Character Suffix



Configuring NLS-HR22

Use the barcode scanner to scan the barcodes below row by row, starting with the top left **Enter Setup** barcode, going from left to right, and ending with the **Exit Setup** barcode.



Enter Setup



Restore All Factory Defaults



Enter Setup



USB COM Port Emulation



Enable AIM ID Prefix



Disable Terminating Character Suffix



Configuring NLS-HR11 Plus

Use the barcode scanner to scan the barcodes below row by row, starting with the top left **Enter Setup** barcode, going from left to right, and ending with the **Exit Setup** barcode.



Enter Setup



Restore All Factory Defaults



USB COM Port Emulation



Enable AIM ID Prefix



Disable Terminating Character Suffix



Configuring NLS-HR42

Use the barcode scanner to scan the barcodes below row by row, starting with the top left **Enter Setup** barcode, going from left to right, and ending with the **Exit Setup** barcode.



Enter Setup







Enter Setup





Enable AIM ID Prefix



Disable Terminating Character Suffix



Configuring NLS-HR3290 (Corded)

Use the barcode scanner to scan the barcodes below row by row, starting with the top left **Enter Setup** barcode, going from left to right, and ending with the **Exit Setup** barcode.



Enter Setup



Restore All Factory Defaults



Enter Setup



USB COM Port Emulation



Enable AIM ID Prefix



Disable Terminating Character Suffix



Configuring NLS-HR15 (Corded)

Use the barcode scanner to scan the barcodes below row by row, starting with the top left **Enter Setup** barcode, going from left to right, and ending with the **Exit Setup** barcode.



Enter Setup



Restore All Factory Defaults



Enter Setup



USB COM Port Emulation



Enable AIM ID Prefix



Disable Terminating Character Suffix



Chapter 9 Maintenance& Troubleshooting

Maintenance

Keeping the NQuire Dust-free

To keep the interior of the NQuire clean and your device at peak performance, please always have the two port covers firmly attached.

Cleaning

Regularly clean the scan window on the bottom of the NQuire with a non-abrasive glass spray cleaner and a soft lint-free cloth to keep it free of dust, dirt and fingerprints. Cleaning can be performed during operation.

When cleaning the housing and display screen, please observe the following instructions:

- Use a mild glass spray cleaner;
- spray the cleaner on a soft lint-free cloth;
- wipe the NQuire clean.

The NQuire should **NOT** be cleaned with cleaners containing aromatic hydrocarbons, chloride, acids or oxidizing agents, abrasives, or other aggressive cleaners.

Note: The display screen and scan window are scratch-sensitive, so please clean them carefully!

Troubleshooting

Problem	Possible Cause	Possible Solution
The NQuire will not turn	No power to the NQuire	Power adapter solution:
on		Connect the approved power adapter to an AC
		power source and to the power jack on the NQuire.
		PoE solution:
		1. Connect one end of an Ethernet cable to the
		Ethernet port on the NQuire.
		2. Connect the other end of the Ethernet cable to
		PoE power module or PoE switch.
		3. Connect DC power to PoE power module or
		PoE switch if required.
		4. Perform continuity check on the Ethernet cable.
The NQuire does not	No communication between	1. Check the cables to make sure they are
respond to pings from	the NQuire and the host	securely connected to the NQuire.
the host computer	computer	2. Ensure the NQuire's IP address is the address
		the host computer is pinging.
		3. Check communication parameters.
The NQuire does not	The NQuire is not connected	1. Check the cables to make sure they are
send data to the host	to the host computer	securely connected to the host computer
computer		2. Check if the NQuire responds to pings from the
		host computer.
Parameter changes	Parameter changes were not	After you change the settings, do not forget to click
made using web-based	saved	on "Apply settings" in the corresponding box(es)
configuration tool were		
not retained after the		
NQuire rebooted		

Appendix

Sample Barcodes





Interleaved 2 of 5



PDF 417



Data Matrix



QR Code



Chinese Sensible Code











Code ID Table

Symbology	Code ID
Code 128	#
EAN128	Р
AIM128	а
EAN-8	FF
EAN-13	F
UPC-E	b
UPC-A	d
ISBN	е
ISSN	g
Code 39	*
Code 93	с
Codabar	%
Interleaved 2 of 5	i
Deutsche 14 (Deutsche Post Leitcode)	h
Deutsche 12 (Deutsche Post Identcode)	j
Standard 25	k
Matrix 2 of 5	1
Industrial 25	m
Code 11	n
MSI-Plessey	0
Plessey	q
GS1 Codabar (RSS)	R
CODE32	t
PDF417	r
QR Code	S
Aztec	Z
Data Matrix	u
EAN413	V
EAN414	w
EAN419	x



Newland EMEA HQ +31 (0) 345 87 00 33 info@newland-id.com newland-id.com **D-A-C-H** +49 (0) 6182 82916-16 info@newland-id.de

Benelux +31 (0) 345 87 00 33 benelux@newland-id.com

Italy +39 (0) 342 0562227 italy@newland-id.com United Kingdom +44 (0) 1442 212020 sales@newland-id.co.uk

South Africa Gauteng: +27 (0) 11 553 8010 Cape Town: +27 (0) 21 9140819 info@newland-id.co.za

Turkey +90 (0) 544 538 40 49 turkey@newland-id.com France +39 (0) 345 8804096 france@newland-id.com

Ibérica +34 (0) 93 303 74 66 info@newland-id.es

Nordic & Baltic +46 (0) 70 88 47 767 nordic@newland-id.com Russia +31 (0) 345 87 00 33 russia@newland-id.com

Middle East +39 (0) 345 8804096 middleeast@newland-id.com

Iran +90 (0) 544 538 40 49 iran@newland-id.com